


Nokia G-2425G Device Step-by-Step Guide for New Customers



Step by step guide on how to connect your newly activated fibre service:

- After the router has been successfully installed, the service is activated within 24-48 hours.
- As soon as the Link and Auth lights on the router is solid green, the fibre service is active.
- Once a service is activated, it is considered 'live' and ready to use immediately.

Note: you may connect wirelessly or via network (LAN) cable.



All information required to connect to the network is provided on the white label at the back of the router (ONT). This includes:

- SSID – default wireless network name
- WiFi KEY – default wireless password



How to connect wirelessly to your computer or laptop:

Step 1: On the bottom right of your Taskbar, click on the connection's icon next to the date and time.



Step 2: A list of available Wi-Fi networks will open. Search for your unique network name (SSID), starting with ALHN, found on the white sticker at the back of your router as per Illustration 1 on page 1 and click Connect.




Step 3: After clicking Connect, you will be prompted to enter the network security key/Wi-Fi password. Enter the WiFi Key, found on the white sticker at the back of your router and click Next




How to connect wirelessly to your cell phone:

Step 1: Go to your cell phone's Settings and search for the Connections option and then select the Wi-Fi option.




Once the connection is successful, a message will display saying "Connected, secured".




You can now start browsing the internet and enjoy your MetroFibre Service!

Step 2: Switch the Wi-Fi on and select your unique network name (SSID), starting with ALHN, found on the white sticker at the back of your router, under Available networks




Step 3: Next you will be prompted to enter the network security key/ Wi-Fi password. Enter the WiFi Key, found on the white sticker on the bottom of the router and click Connect.



You can now start browsing the internet and enjoy your MetroFibre Service!

How to change/personalize your Wi-Fi name and password:

Step 1: With the router connected to your PC (for this step a LAN connection is preferred), open a browser and enter the admin IP found on the white sticker on the bottom of your router into the address bar and then press enter.




Step 2: The Login page will open and prompt for a Username and Pass- word



Enter the Username and Password credentials found on the sticker of your router and click on the Login button.



Step 3: On the Home Gateway Page click on the Network dropdown and select WiFi:



Step 4: Enter your new Wi-Fi network next to SSID Name and new password next to WPA Key then click Save.



Please Note: You will need to reconnect any devices that were previously connected via Wi-Fi using the new credentials you created. For any assistance, kindly contact our Support Team on 087 151 4000 or send an e-mail to sales.support@metrofibre.co.za.